

1. Steps for Door-opening Record Checking

Step1. Card issuing:

Click  in the main interface → Click  → Put the Record Card (TEMIC LOCK is any kinds of TEMIC Card and Mifarel LOCK is S70 Card) on the Card Reader induction zone → Click .

Step2. Record downloading:

Download the Door-opening Record into Record Card (Mifarel LOCK) or Collection Device/Encoder/Collector (TEMIC LOCK).

If Mifarel LOCK, the card should be put over Door Lock's Induction Zone 1cm and then the indicator LED will flash, still where it is for 20 seconds. When hearing one "beep", the download procedure finishes successfully.

If TEMIC LOCK, Collector with four 7# batteries must have been prepared. Turn on Collector which green light will light on after two beeps. Swipe the Record Card over the Lock Sensor and put away, and pull the Collector near to Lock Sensor (as following picture) within 3 seconds, then the red LED of Collector will glitter regularly which stands for that the Collector is in the course of download that need about 30 Seconds. Turn off the Collector immediately after finishing collection.



How to download the records to the collector

2. Record uploading:

If Mifarel LOCK, put the Record Card on the induction zone of Card Reader directly.

If TEMIC LOCK, connect the Collector to computer after finishing collection for downloading the records, after, turning it off.

Follow the below steps to fetch the records:

Click  →Select” Report of Open Door”→Click  →Operate as the indication showed.