

[illegible]

[illegible]



1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40	41	42	43	44	45	46	47	48	49	50	51	52	53	54	55	56	57	58	59	60	61	62	63	64	65	66	67	68	69	70	71	72	73	74	75	76	77	78	79	80	81	82	83	84	85	86	87	88	89	90	91	92	93	94	95	96	97	98	99	100
---	---	---	---	---	---	---	---	---	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	-----

[illegible]

1. .
 2. .
 3. .
 4. 500000 .
 5. MOV .
 6. .
 7. .
 8. .
- :
 :
 :
 :.

المتاحة OEM/ODM ، صور مفصلة



1

Aluminum alloy

Power off the open circuit design,
once locked In addition to power
or the lock tongue can not

2



3

To prevent illegal insert fragment
magnet lock, after the lock is not
affected by External disturbance




Hex socket screw

4





5

Time delay with 0/3/6Second




STANDARD INSTALLATION STEPS


Professional guidance, Rest assured



1 Fold the plate to 90° .




2 Close the door first, then place the upper side of template on door frame, while adjust the left side next to the door leaf.




3 Mark screw positions of armature plate and magnetic lock on door leaf and door frame respectively.




4 Drill holes based on the marked positions.




5 Make a combination based on the picture.



6 Strike the pin into the armature plate slightly (to avoid movement).




7 Make a combination based on the picture (add washer accordingly). The rubber ring must be added.



8 Place the rubber ring between armature plate and door leaf.




9 Use Allen key to remove the mounting plate from lock body.




10 Fix the mounting plate on the door frame according to the holes drilled earlier.




11 Use Allen key to screw the lock body on the mounting plate.




12 Close the door to test holding force. The angle between armature plate and magnetic lock can be adjusted by adding or reducing washers.




13 After all the appropriate procedures, the holding force can be maximized. Finally, fix the tamper screw.



Hollow Metal Door
Drill a hole
Inside: Diameter is 8mm
Outside: Diameter is 16mm



Wooden Door
Drill a hole
Inside: Diameter is 8mm
Outside: Diameter is 12.7mm



Metal Surface Door
Inside: Drill a hole
diameter is 8mm folding
the plastic straight pin

Notice:

Thickness of Door Leaf:

350LBS: 44mm

600LBS: 50mm

800LBS: 48mm

1200LBS: 46mm

المنتجات الموصى بها

طريقة الشحن

يمكن شحن المنتجات عبر DHL، FEDEX، TNT، UPS، EMS، أو البريد العادي. يرجى اختيار الطريقة المناسبة من القائمة أدناه.

التعبئة والتغليف

تعبئة قفل الترياس: وحدة واحدة لكل صندوق، 20 قطعة لكل كرتون،

م، الوزن الإجمالي: 14 كجم. 50 كرتون لكل منصة نقالةCحجم الورق المقوى: 12*29*52



المنتجات الموصى بها

□□□ 3 □□□ □□□□□□ □□□□ □□ □□□□□ □□□□ □□ □□□!!!

000000 000000 00 0000000 00000000 0000000 000000 000000000 0000 00000000 00 000000 20 0000000 0000000
 "0000" 000 0000 0000000 00000000 000000 00000 00000 !000000 00 0000000 0000 000000 00 0000 000000 00
 !00000

[illegible]

□□ □□ □□□-Y100S 2PIN

100 mA / 900 mAPower 2 PIN

□□ □□ □□□-Y500A

□□□□□□ □□□□ □□□
□□□□□ □□□□ □□□□□ □□□□□ □□□□□ NC

ACM-Y100S 5PIN

ACM-Y100S 5PIN
ACM-Y100S 5PIN
5 ACM-Y100S 5PIN

You May Need



ACM-Y280

280) ACM-Y280
600/280)

ACM-Y100S

مستشعر الباب المغلق (NC/NO) مستشعر الباب المغلق
مستشعر الباب المغلق PVC

مستشعر الباب المغلق-Y066

(مستشعر الباب المغلق) مستشعر الباب المغلق
130 :مستشعر الباب المغلقx98x41mm مستشعر الباب المغلق

قوس الحاجة لقفل الباب ديدبولت



مستشعر الباب المغلق-Y700

مستشعر الباب المغلق مستشعر الباب المغلق مستشعر الباب المغلق
مستشعر الباب المغلق مستشعر الباب المغلق

لوحة التحكم -Y600

لوحة التحكم للباب الكهربائي
لوحة التحكم للباب الكهربائي

لوحة التحكم -Y601

لوحة التحكم للباب الكهربائي

مجموعة كاملة من الحلول للتحكم في الوصول إلى الباب



لوحة التحكم -WEG02

لوحة التحكم للباب الكهربائي
(RS232 أو RS485 أو TCP/IP Communication)

□□ □□ □□-K2A

□□□ □□□□ □□□□□□ □□□□□□ □□□
K2A: 115*40 □□□ K2B: 86*86 □□

□□ □□ □□-Y806-3A

□□□□□ 3/□□□□ 12 □□□□□□□ □□□□ □□□□



□□ □□ □□-Y280

280) □□□□□ □□□ □□□□ □□□□□□□ □□□
□□□ 600/□□□)

□□□26-□□ □□ □□□

125 □□□□□ 26/34 □□□□□□ □□□□ □□□□
□□ 16.8 × □□ 75.5 × □□ 115 :□□□□□□

EM-S

EM 125

3

20
 "
 !
 .

24
 2
 3
 4
 5
 (1
 (2
 (3
 30 ~ 7
 5 ~ 1
 :
 7: T/T Western Union Paypal Ali
 8 DHL FEDEX TNT UPS EMS
 .
 ضمان الجودة
 - ACM Goldbridge
 .
 - ACM Goldbridge .
 -.

ACM

RFID
 20
 RFID
 :
 RFID
 RFID
 RFID
 UHF

