



CAUTION  LASER LIGHT WHEN OPEN
DO NOT STARE INTO BEAM

Complies with CE, IEC 60825-1 and IEC 60825-2
permanently Laser Notice No. 35 dated July 18, 2017
THORlabs 11100AVAL 2000-2000-0000
ACCURACY: 1/8" @ 100' ± 0.001"
FLARE LASER PRODUCTS • 1-800-451-7273
















How to Use This Barcode Scanner?

1. For better scanning function, please hold this scanner at right angle, don't decode it at 90°.



2. For truly decoding the barcode, scanning laser must cover the whole barcode.



How to Assemble/Disassemble the Cable?

Plug sharp things like toothpick or clip into the right hole and then pull out the cable easily.





Shakeproof



Super decoding



Compatible
different terminal



High Cost-Effective

WE PROVIDE THE MOST COMPLETE
PROFESSIONAL SCANNING APPLICATION



Logistics express
barcode



Supermarket
barcode



Medical
barcode



Factory
inventory



Machine
customization

Shipping







ACM26X RFID

125Khz wiegand 26/34
115mm×75.5mm×16.8mm

ACM26G RFID

125Khz /13.56Mhz
26/34 / RS232

KR600E RFID

125KHz ID / 13.56Mhz
26





ACM-EMI-S RFID

125Khz EM
86 * 54mm

ACM-MF1 RFID

MF1 1K

ACM-ABS003 RFID

125Khz EM / 13.56Mhz / UHF
2



-ACM Goldbridge

-

□□□□□□

124

2

3OEM / ODM

4fashin desing

5

1

2

323

615730

7T / TPaypal

8DHL FEDEX TNT UPS EMS

□□□□

Q1.

A

Q2.

A T / TPaypal

DHL FedEx TNT UPS

Q3.

A

Q4.

A500037100,000715

Q5.

A OEM

Q6.

20RFID NFC RFID rfid1