



Wedge-shaped Design

If an intruder attempts to enter, the unit will wedge underneath the door .

Sensitivity Switch

Allows you to adjust the amount of movement required to set off the alarm.

Power On/Off

Non-skid Pad

Prevents door from opening and immediately activates an alarm.

Powerd by one 9V battery



- Live alone
- Travel
- Protect the elderly
- Hotel

