

000 00 **ZK** 000 00 000 0000 00 00 000 00 00 0 00

.  $\bigcirc$  4  $\bigcirc$  0  $\bigcirc$ 

V10.0 000, 00 00 000 3.Fingerprint & ID 000 000;

- \_\_\_\_\_ 4.Infared \_\_ \_\_;
- 5. 000 000 00 00, 00 00, 00 000;
- $6. \ \Box\Box\Box\Box \ \Box \ \Box\Box\Box \ \Box\Box\Box \ \Box, \ \Box\Box \ \Box\Box\Box \ \Box\Box \ \Box\Box \ \Box\Box \ \Box\Box \ \Box\Box$
- 7.No 0000 00 000 00, 000 0000 0000;
- 8. 00 00 000, 000 000 00000.


# 

ACM-851 00 00 00 00 00 Rfid 00 000 00 0 00 00

- $4 \ \square\square \ \square\square \ \square\square$
- 1.
- 2.
- 3.
- $4. \square \square + \square \square \square \square$




### $\ \, \square\square\ \, \square\square\square\square\square\ \, \square\ \, \square\square$




### Install the machine




Remove the bottom screw




2. Take the back cover off the machine.




Focus the drilled hole on the wall and fix the back cover on the wall by screws.



Install the machine on the fixed back cover.



Fix the machine on the back cover.



6. Tamper resistant switch








# **ACM223**

 $\bigcirc\bigcirc$   $\bigcirc\bigcirc$  RFID  $\bigcirc$   $\bigcirc\bigcirc\bigcirc$   $\bigcirc\bigcirc$   $\bigcirc\bigcirc$  , 125Khz EM 1000/4000  $\bigcirc\bigcirc\bigcirc$   $\bigcirc\bigcirc$ 

# **ACM209-NW**

 $\bigcirc\bigcirc\bigcirc$   $\bigcirc\bigcirc$  RFID  $\bigcirc\bigcirc\bigcirc$   $\bigcirc\bigcirc$   $\bigcirc\bigcirc$   $\bigcirc\bigcirc$   $\bigcirc\bigcirc$   $\bigcirc\bigcirc$   $\bigcirc\bigcirc$  , 125Khz EM

### **ACM208**

 $\ \ \square$  RFID  $\ \ \square$   $\ \ \ \square$   $\ \ \square$   $\ \ \square$ 







### **ACM210**

 $\ \square$  RFID  $\ \square$   $\ \square$   $\ \square$   $\ \square$   $\ \square$   $\ \square$ 

### **ACM225**

 $\hfill \square \square$  RFID  $\hfill \square \square$  , 125  $\hfill \square \square$  EM, wiegand  $\hfill \square \square$  connect  $\hfill \square$ 

# **ACM211B**

 $\hfill \square$   $\hfill \square$   $\hfill \square$   $\hfill \square$  wiegand  $\hfill \square$  connect  $\hfill \square$   $\hfill \square$   $\hfill \square$ 

- 1, 00 24 00 000 00
- 3, [[[]] OEM / ODM
- 4,  $\Box\Box$ , fashin desing,  $\Box\Box\Box$   $\Box$   $\Box\Box\Box\Box$
- 5, 00 000 :
- 1), 00 000 0000 00 00 0 00 00
- 2), 00 000 00 00 0 00000
- 3), 000 00 000 2-3 0 00 00 00 000 00 000
- 7, 00 : 00 00 00 : T / T, 000 000, 000, 00 00 00



#### **Q** : **1**. [[[] [[]]?

### Q: 2. | | | | | | | | | | | | | | |

 $\begin{picture}(2000)(1000)($ 

#### Q: 3. [[[] [[]] [[]]?

: 000 00 000 00, 00 000 00.

### **Q**: **4**. 000 000 00 00 0 0000?

#### Q:5.000000000000000000000

#### **Q**: **6**. 000 00 00 00 00?